

# GABARITO 1 - INFERIOR

23 cm

CHAPA 1ª

Flecha 4 cm



## Medidas

- 1 cm = 1 cm
- 2 cm = 1.5 cm
- 3 cm = 2.2 cm
- 4 cm = 2.7 cm
- 5 cm = 3.1 cm
- 6 cm = 3.4 cm
- 7 cm = 3.7 cm
- 8 cm = 3.9 cm
- 9 cm = 3.9 cm
- 10 cm = 4.0 cm
- 11 cm = 4.1 cm
- 12 cm = 4.1 cm
- 13 cm = 4.0 cm
- 14 cm = 3.8 cm
- 15 cm = 3.7 cm
- 16 cm = 3.4 cm
- 17 cm = 3.2 cm
- 18 cm = 2.6 cm
- 19 cm = 1.7 cm

- 20 cm = 1.7 cm
- 21 cm = 1.1 cm
- 22 cm = 0.6 cm

Chapa total inferior

