

— THE WORK MUST BE CLEANED WITH DRY CLOTH.

— THIS WORK MUST BE INSTALLED ON A CORNER OF A BUILDING.

THE HIGHER POINT (A) MUST ALWAYS BE AT THE LEFT HAND SIDE OF THE CORNER.

OBVIOUSLY, THE LOWER POINT (B), MUST BE FIXED AT THE RIGHT HAND SIDE OF THE CORNER.

POINT A IS FIXED ON THE WALL AT 4.00 M HIGH AND AT 4.00 M DISTANCE FROM THE CORNER.

POINT B IS FIXED ON THE WALL AT 1.00 M HIGH AND AT 6.20 M DISTANCE FROM THE CORNER.

THE SQUARED METAL PIECES WHERE THE TUBE IS WELDED MUST BE FIXED ON THE WALL 2 CM UNDER THE WALL LEVEL, IN ORDER TO BE COVERED WITH PLASTER AND PAINTED.



THE WORK CAN BE FIXED ON THE WALL WITH 4 BOLTS FOR EACH PLATE OR USING HILTI HIT HY 150

A SCAFFOLD MUST BE USED TO ACHIEVE THE HIGHER POINT AND WOODEN STRUCTURES (AS USED FOR PACKING THIS WORK) CAN BE USED TO SUPPORT 4 OTHER POINTS OF THE TUBE DURING

THE FIXATION OF THE WORK. SIX ASSISTANTS WILL BE NEEDED: TWO AT POINT A AND B AND FOUR AT THE 4 WOODEN STRUCTURE

